


Guide for Lumaline counter artwork

1. Download the artwork templates at our website:
<http://www.tech-view.com/download/luma-index.html>
Choose between Adobe Illustrator and InDesign template (CS3)
2. Open the document for your selected Lumaline counter, large or small.
3. Place your artwork in the layer “Your Artwork”.



Your artwork could be vector- or bitmap graphics or both. We recommend your bitmap-artwork should be no less than 100dpi in 100%.

Use Pantone colors if needed, but please advise us if you do.

Artwork size for Large counter: 980 x 2900mm (38,6 x 114,2")
(Sheet size 980 x 3554mm)

Artwork size for Small counter: 980 x 2430mm (38,6 x 95,7")
(Sheet size 980 x 3084mm)


Make sure your main message or logo is centered and no wider than 100cm (small counter) or 130cm (large counter), see layer ‘visible area’.




The white SPOT layer (marked as magenta) is placed in the top layer, as the artwork is printed mirrored on the transparent polycarbonate sheet.

The black cover-bars serve to dim the light inside the counter in specific areas.

Your main message/logo will be presented at the front of the counter, as illustrated on the next page --->



Your artwork will be presented on the counter as shown below. You can go to our website to get an idea of how the counter presents itself in 3D:
http://www.tech-view.com/lumaline/unit_s-514-2.html



5. Prepare files for us:

Print to Adobe Acrobat with ‘Press Quality’ settings in 100%, no bleed, no cropmarks. Make sure to select ‘Composit Leave Unchanged’ in output.

Or, make a package from Indesign / save as ai from illustrator, with links and fonts included.

6. Send us the files via our ftp-server and let us receive an e-mail with your request and specifics. To send files, go to: <http://www.tech-view.com/ftp> and follow the instructions.